

## TECHNICAL DATA SHEET

### Oak Shadow Grey, brushed & oiled



#### PRODUCT DETAILS

Product range	BRUSHED lightly textured
Available formats	Boards, herringbone, chevron
Sizes	Board widths: 160mm / 195mm / 245mm / 280mm / 310mm
	Board lengths: Variable between 2m and 2.4m (280mm and wider are produced in 3m - 5m lengths)
	Herringbone and chevron parquet: 120mm x 780mm or similar
Depth	11mm (up to a width of 195mm), 15mm and 20mm
Construction	Engineered 3-layer construction
Finish	Lightly brushed and colour-oiled
Profile	Tongue and groove
Edge profile	Micro bevelled
Wear layer	4mm

#### WARRANTY AND INSTALLATION

Manufacturer's warranty: 5 years, subject to terms and conditions. Note there is no warranty on the finish as we have no control over usage and aftercare. All our floors must be installed by a competent installer onto a firm, level (flat), clean and dry substrate. The site must be heated if necessary and water tight with all glazing fitted. Wet works such as plastering and tiling must be completed prior to installation.

#### GRADES

Prime	Occasional, small knots up to 15mm
Classic	Knots up to 40mm, including filled knots no sapwood
Rustic	Frequent knots up to max. 80mm, including filled knots and cracks up to 400mm, sapwood up to 10mm

#### TECHNICAL CRITERIA

Origin	Europe
Certification	PEFC, FSC on request
Formaldehyde emission	E1
Thermal conductivity	0.17 W/mk for 20mm depth 0.12 W/mk for 15mm depth 0.08 W/mk for 11mm depth

#### MAINTENANCE

Initial care & re-oiling	<ul style="list-style-type: none"> <li>Do not clean the floor with water in the first 4 weeks after installation</li> <li>Under no circumstances should any chemicals/white spirit/detergent cleaners be used as these will remove the protective oiled finish</li> <li>We recommend a final coat of oil after installation</li> <li>Re-oil every 2-5 years depending on the volume of traffic. High usage areas may require annual re-oiling</li> <li>Use Osmo Polyx Raw or Osmo Polyx Hardwax Oil Clear Satin</li> <li>Prior to re-oiling wash the floor with Woca Wood Cleaner and leave to dry for 4 hours</li> </ul>
General cleaning	<ul style="list-style-type: none"> <li>Use Osmo Wash and Care soap for regular cleaning and Osmo Liquid Wax Cleaner Spray for stubborn stains</li> <li>Do not rub individual spots as you risk removing the layers of coloured oil and revealing the natural surface of the wood. Carefully clean off marks with Osmo Liquid Wax Cleaner Spray</li> </ul>

#### INSTALLATION METHODS

Fixed installation	Highly recommended, either fully bonded or secretly nailed
Floating installation	Possible depending on room size and only up to a board width of 245mm
Over underfloor heating	This floor is compatible with UFH. Floors must be fully bonded to the substrate  The temperature of the floor surface must not exceed 27 degrees. Floor sensors must be installed to monitor the maximum temperature

Waxed Floors, 92 Battersea Rise, SW11 1EJ, London  
T. +44 20 7738 1620 F. +44 20 7738 1630  
sales@waxedfloors.co.uk www.waxedfloors.co.uk

The company reserves the right to change this specification at any time without prior notice to third parties. The image is intended as a guide only and should not be regarded as absolutely accurate.