Oak Ecru - 03/2025

# Oak Ecru

# PRODUCT DETAILS

WAXED FLCORS

Species	European Oak		
Construction	Plywood engineere	ed (birch)	
Texture	Planed		
Patterns	4s panel / Boards / Herringbone / Vers	Boards in mixed widt ailles panel	hs / Chevron /
	4s panel	Boards	Boards in mixed widths
	Chevron	Herringbone	Versailles panel
Boards Width Boards Lengths Herringbone sizes Chevron sizes	145mm / 185mm / 225mm / 245mm / 285mm Varied 1500 – 2500mm 85 x 425mm / 145 x 580mm 85 x 510mm / 145 x 725mm		
Depth / top layer ( +/- 0.5mm)	12 / 3mm (12mm depth with a wear layer of +/- 3mm)*, 15 / 4mm (15mm depth with a wear layer of +/- 4mm)**, 20 / 6mm (20mm depth with a wear layer of +/- 6mm)		
	* Maximum board width: 220mm ** Maximum board width: 285mm		
Edge profile	Micro bevel, No bevel (square e	dge)	

# **TECHNICAL CRITERIA**

Origin	Holland
Formaldehyde Emission	El Engineered floors classified as El do not emit more than 0.1 ppm of formaldehyde into the ambient air and are 100% safe for interior use.
Certification	FSC (Forest Stewardship Council) – certification on request PEFC,
	EU and UK Timber Regulation compliant

The company reserves the right to change this specification at any time without prior notice to third parties. The image are intended as a guide only and should not be regarded as absolutely accurate.



Oak Ecru, planed



### **GRADES CRITERIA**

Grades	Rustic / Rustic A / Premier
Rustic	Large and frequent knots including large, filled knots become a feature of the overall look. Rustic grade allows for a wide range of variation in colour and grain. The colour of the filler is intended to compliment the colour of the wood and may vary from batch to batch.
	<ul> <li>Knots up to 80mm</li> <li>Filled knots, cracks, and other imperfections</li> <li>Centre core</li> <li>Natural colour variation</li> <li>Sapwood up to max. 25mm (on long side of boards)</li> </ul>
Rustic A	Rustic A grade is a selection of premier grade and 'good' rustic grade material. It contains knots including filled knots up to 40mm in size. The colour of the filler is intended to compliment the colour of the wood.
	<ul> <li>Knots up to 40mm, including filled knots</li> <li>Occasional, small cracks up to 20mm</li> <li>Natural colour variation</li> <li>Occasional sapwood up to max. 10mm</li> </ul>
Premier	Premier grade has an even appearance with very few, small knots. The natural variation is limited, though can be more visible on fumed oak.
	<ul> <li>Occasional knots up to 15mm</li> <li>Occasional, small cracks up to 20mm</li> <li>Natural colour variation</li> <li>No sapwood</li> </ul>

Please note the selection process of prime/ premier grade boards wider than 245mm is usually more relaxed. The aim is to select calm boards with the minimum number of knots and grain variation.









#### **STAIR SOLUTIONS**

2	Nose Dr Dutch Bullnose, round
2	Nose Dp Dutch Bullnose, pencil round
	Nose Vr Victorian Bullnose, round
	Nose Vp Victorian Bullnose, pencil round
	Nose Sp Square Nose (no overhang), pencil round
	Nose Se Square Nose (no overhang), bevelled
 	Custom treads available on request

## **COLOUR VARIATION**

Non-fumed	Non-fumed tones have less variation in colour compared to fumed tones. Please note, the natural variation can vary between batches.
	Please read our installation guide for information on how to achieve a harmonious looking floor.

# PACK SIZE

Varied, between 1.6-2.5m<sup>2</sup>, Varied, depending on parquet size and pieces per pack

## **INSTALLATION METHODS**

Fixed installation	Secretly nailed or fully bonded.
Fully bonded over underfloor heating	Suitable for installation over underfloor heating. Floors must be fully bonded to the substrate. The temperature of the floor surface must not exceed 27 degrees.
	Please refer to our comprehensive installation guide for

more information.



## **RECOMMENDED OIL FOR TOPCOAT**

Floorservice Maintenance oil Antique White,

Osmo Polyx Hardwax Oil Clear Matt 3062 applied by roller/brush,

Osmo Polyx Hardwax Oil Raw Transparent 3044 applied by floor buffer/ white pad

Please read our guide on post installation requirements and application of the topcoat of oil.

## MAINTENANCE

For regular damp mopping use the Osmo Wash & Care Soap

Please read the maintenance guide/o+m available from Waxed Floors.